

1524 Control Board Removal

(These instructions are for the Laguna 1524 Lathe)

Follow the steps provided in this instruction manual to perform a control board removal of your Laguna lathe successfully.



You will need the following.

1



1. Phillips Head Screwdriver

By the end of these instructions, you will know how to.

- **Access the control board.**
- **Remove/Replace the control board.**

It's recommended to have a cup/bowl to hold the screws as they are very small. Sweeping the floor around the workspace will increase the chance of recovering a screw if one is dropped.

STEP 1

Remove power from the machine by unplugging the unit and waiting at least 1 minute.



STEP 2

Remove the 4 screws securing the cover to the headstock and remove the cover to expose the control board.



STEP 3

Remove the 6 screws securing the board to the back of the headstock.



PARTS

The parts below are hyperlinked and will take you to the parts page located at lagunatools.com.

34

Control Board

[415241-134](#)