

V10/G8 Stand Assembly Instructions

Part Number: 110001



LAGUNA

Laguna Tools

744 Refuge Way, Suite 200

Grand Prairie, TX 75050

lagunatools.com

V10/G8 Stand Assembly Instructions

Scope of This Manual

This manual outlines the basic procedures for unpacking and assembly for V10/G8 stand.

For detailed instructions and videos, please go to www.lagunatools.com. Refer to www.lagunatools.com for the latest manual revision.

Customer Service

For technical support, please contact Laguna Tools Customer Service by phone 1-800-332-4094.

Copyright © 2025

Laguna Tools, Inc.

ALL RIGHTS RESERVED

This document contains material protected under International and Federal Copyright Laws and Treaties. Any unauthorized reprint or use of this material is prohibited. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system without express written permission from the author/publisher. LAGUNA® and the LAGUNA Logo® are the registered trademarks of Laguna Tools, Inc.

DISCLAIMER

Laguna Tools is not responsible for errors or omissions. Specifications subject to change. Machines may be shown with optional accessories.

Revision: R01 (06/04/2026)

V10/G8 Stand Assembly Instructions

1.0 General Information and Safety

1.1 Overview

SAVE THIS MANUAL. Read this Owner's Manual in its entirety prior to assembly.

Read and understand all warnings and operation instructions before using any tool or equipment.

Always follow basic safety precautions to reduce the risk of personal injury. Improper operation, maintenance, or modification of tools or equipment could result in serious injury or property damage. Laguna Tools equipment is designed for specific and limited applications. This product should not be modified nor used for any application other than its intended use.

PERSONAL SAFETY IS THE RESPONSIBILITY OF THE OPERATOR.

1.2 Intended Use

This accessory is designed to provide heightened support for the V10 bandsaw or the G8 grinder.

2.0 Specifications

V10/G8 Stand Specification Table	
Maximum Height	30.75" (781mm)
Minimum Height	24" (609mm)
Top Mounting Surface (length x width)	16.5 x 10.75" (419 x 273mm)
Footprint (length x width)	27.5" x 20.5" (700mm x 520mm)

3.0 Setup and Assembly

Please carefully read and understand all setup and assembly instructions before beginning this procedure.

WARNING

Seek assistance from an experienced professional if you have any doubt about the following unboxing or set up procedures.

V10/G8 Stand Assembly Instructions

3.1 Packaging Contents

(4x) Rubber Feet



(2x) Long Lower Brace



(2x) Short Lower Brace



(2x) Short Upper Brace



(2x) Long Upper Brace



(4x) Leg



V10/G8 Stand Assembly Instructions

(2x) Center
Support



(4x) Extension
Leg



J Hardware Bag
(not shown)

Remove all contents from the shipping boxes. Do not discard the carton or packing materials until the assembly is complete. There may be extra packing contents or hardware that is included.

3.2 Tools Required for Assembly

- 13mm wrench and socket
- 10mm wrench and socket (if using V10 Bandsaw)
- 16mm wrench and socket (if using G8 Grinder)

3.3 Assembling the Machine

Hand tighten all bolts and nuts until the end of assembly. This stand can be purchased with optional casters (sold separately).

1. Remove all packaging contents from the box.
2. Attach the feet to the bottom of the extension legs.
 - a. Secure the jam nut.
 - b. Repeat this process for all extension legs.




V10/G8 Stand Assembly Instructions

3. Attach the extension leg to the inside of the main leg and secure with four bolts and nuts. Hand tighten the nuts. Ensure the threads face the inside of the leg.
 - a. Repeat this process for all legs.
 - b. Adjust the extension leg position to desired height.



4. Attach the short upper brace to the outside of the two legs with four bolts and nuts.





5. Attach the short lower brace to the middle of the legs with two bolts and nuts.
 - a. Repeat for the other legs.




V10/G8 Stand Assembly Instructions

6. Place the long upper brace *above* the leg and *below* the short upper brace. Secure the legs with two bolts and nuts. Hand tighten the nuts.



8. Attach the other long upper brace to the other side. The stand should now be similar to the figure below.




9. Attach the long lower braces to the inside of the legs. Secure with bolts and nuts.



V10/G8 Stand Assembly Instructions

10. Slide the center supports in place and secure with the bolts and nuts. (If using the V:10 bandsaw, the center supports are recommended but not required).




11. Make sure that all components and hardware are installed. (there may be some extra hardware)
12. Use a 13mm wrench and socket to tighten all fasteners.

The casters shown below are sold separately. Contact Laguna tools to purchase the casters.

For easier installation, it is recommended to place a piece of material under the leg to lift the stand off the ground.

7. Remove the bolts from the casters.
8. Position the caster inside the extension leg, aligning it with the second and third bottom holes.
9. Secure with the bolts and tighten with a 13mm wrench.
10. Repeat these steps for all casters.




V10/G8 Stand Assembly Instructions

11. With the wheel lock engaged (lever up), adjust the leveling feet to sit slightly below the wheel. The stand should not move when the lever is up. Adjust feet as needed.


The stand should roll freely when the wheel lock is disengaged (lever down).

12. With the help of another person, lift the desired machine onto the stand, aligning the holes.




13. If using the **V:10 Bandsaw**, align the four corner holes with the stand.

- Locate the four bolts that have two washers and two nuts on each of them.
- Place a washer on top of the bandsaw corner hole and slide the bolt through.
- From the underside, place a washer and the two nuts on the bottom of the bolt.
- Use a 10mm wrench and socket to tighten. Tighten the top nut and then the bottom nut.




V10/G8 Stand Assembly Instructions

14. If using the **G:8 Grinder**, align the two holes with the grinder slots.
- a. Align the bolt and large washer over the grinder slot and insert it into the hole.



- b. From the underside, place the nut on the bolt and tighten using a 16mm wrench and socket.



V10/G8 Stand Assembly Instructions

4.0 Warranty

WARRANTY & REGISTRATION

Thank You!

Welcome to the Laguna Tools® group of discriminating woodworkers. We understand that you have a choice of where to purchase your machines and appreciate the confidence you have in the Laguna Tools® brand.

Through hands-on experience, Laguna Tools® is constantly working hard to make innovative, precision products. Products that inspire you to create works of art are a joy to operate and encourage your best work.

Laguna Tools®
Imagination, Innovation, and Invention at Work

Warranty & Registration

Every product sold is warranted to be free of manufacturer's defective workmanship, parts, and materials. For any questions about this produce, the intended use or what it was designed for, customer service, or replacement parts, please contact our customer service department:

Laguna Tools® Customer Service
744 Refuge Way, Grand Prairie, Texas 75050, USA
1-800-234-1976
www.lagunatools.com/why/customer-service/
8AM. To 5PM PSF. Monday through Friday

For warranty claims or to report damage upon receiving-please reach out to our warranty department:

Laguna Tools® Warranty Service
744 Refuge Way, Grand Prairie, Texas 75050, USA
1-800-234-1976
www.lagunatools.com/policies/warranty
8AM to 5PM PST, Monday through Friday

Registration

To prevent voiding this warranty, all products sold must be registered within thirty (30) days of receiving the product. Registering the product will enable the original purchaser to receive notifications about important product changes, receive customer service, and be able to file a warranty claim against defective workmanship, parts, or materials.



Who is Covered

The applicable warranty covers only the initial purchaser of the product from the date of receiving the product. To file such claims, the original purchaser must present the original receipt as proof of purchase.

What is Covered

The warranty covers any defects in the workmanship of all parts and materials that make up the machine unless otherwise specified. Any part determined by Laguna Tools® to have a defect will be repaired or replaced (and shipped), without charge. The defective item/part must be returned to Laguna Tools® with the complaint and proof of purchase in the original packaging that it was received in. In the event the item/part is determined to be not covered by this warranty, the customer will be responsible for the cost to replace the item/part and all related shipping charges.

Warranty Limitations

This limited warranty does not apply to natural disasters, acts of terrorism, normal wear and tear, product failure due to lack of maintenance or cleaning, damage caused by accident, neglect, or lack-of inadequate dust collection. The warranty may be voided against proof of misuse/abuse, damage caused where repair or alterations have been made or attempted by others, using the product for purposes other than those described as intended use (unless with consent by Laguna Tools®), modification to the product, or use with an accessory that was not designed for the product. It is the responsibility of the user to understand basic woodworking machinery settings and procedures and to properly maintain the equipment in accordance with the standards provided in this manual.

Length of Warranty

All new machines and optional accessories sold through an authorized dealer carry a two-year warranty effective from the date of receiving the product. Machines sold for either commercial or industrial use have a one-year warranty. Wearable parts like throat plates, bandsaw guides, etc., have a ninety-day warranty.

Table A-1 Warranty Lengths

2 Year – New Machines Sold Through an Authorized Dealer
2 Year – Accessories Sold as Machine Options (excluding blades)
1 Year – Machines Sold for Commercial or Industrial Use
1 Year – Blades and Accessories outside of Machine Options
90 Days – Wearable Parts

Aside from being free of defects upon receiving, consumable parts, like cutters and abrasives, are not covered by this warranty unless otherwise stated by Laguna Tools®. These parts are designed to be used at the expense of the operator and are available for replacement or inventory purchase. The determination of a consumable part will be made on a case-by-case basis by Laguna Tools®.

Shipping Damage

Laguna Tools® is not responsible for damage or loss caused by a freight company or other circumstances not in the direct control of Laguna Tools®. All shipping-related claims for loss or damage to goods must be made to Laguna Tools® within twenty-four hours of delivery.

How to Receive Support

To file a warranty claim, please contact the warranty department at 1-800-234-1976. To receive customer service or technical support, please contact the customer service department at 1-800-332-4094. Parts, under warranty, are shipped at the expense of Laguna Tools® either by common carrier, FedEx ground services, or similar method. Technical support to install replacement parts is primarily provided by phone, fax, email, or the Laguna Tools® Customer Service Support Website.



© 01/2025 Laguna Tools, Inc.



Laguna Tools, Inc.

744 Refuge Way, Suite 200

Grand Prairie, TX 75050

1-800-234-1976

www.lagunatools.com

Copyright © 2025 Laguna Tools, Inc. All rights reserved.